



## **DESIGNTEK TAIL PIPE TRIMS**

PART NUMBER: 3606409703

# Fitting instructions



**Tools Requires:**

- 3/8" Ratchet
- 3/8" Extension
- 3/8" 13mm socket

**Instructions:**

1. Loosen 13mm nut that holds tailpipe to back box.



2. Remove old exhaust tips.
3. Check which sleeve is required to fit your back box and slide onto exhaust exit pipe.
4. Slide new exhaust trim on to back box onto sleeve installed in point 3.



5. Align trim with bumper and tight 13mm nut to hold in place.